



It is recommended that some form of USB access is implemented even if this is not required functionality to allow debug and simplified production configuration.




**Simple USB Connection**


RESET does not need to be connected unless external reset control is required as part of user function



**VTAP25 Module**



**Buzzer Circuit**



**Antenna with Matching Circuit**

Title: VTAP25 Host Powered Example (Second Draft)  
 Variant: [No Variations] -  
 Assembly Revision:

**A4**

DRAWING NO  
 [No Variations]-Scm

© COPYRIGHT  
 This drawing has copyright and may not be copied in whole or in part or used for any purpose other than that for which it is supplied without express written consent.

**DOT ORIGIN Ltd**  
 Unit 7, Coopers Place, Combe Lane  
 Wormley, Godalming  
 Surrey, GU8 5SZ, UK  
 Tel: +44 (0)1428 685 861  
 Email: [vtap-support@dotorigin.com](mailto:vtap-support@dotorigin.com)

Sheet 1 Of 1	DATE <b>12Feb2025</b>
REV <b>2</b>	Drawn <b>Dot Origin Ltd</b>
ECN <b>N/A</b>	